SECTION 13

Rear & Side Engine Doors

1. Change rear engine door micro switch supplied by BAC.

2. Change N/S engine door start inhibit micro switch supplied by BAC.

3. Fit new Southco locks to N/S engine door. Replace damaged/missing side engine door catches/foam strips and adjust new locks to remove any rattles in engine doors when closed.