

Table 3 Minimum Effective Clear Widths of Doors	
Direction and Width of Approach	Minimum Effective Clear Width^(a)
Straight on (without a turn or oblique approach)	800 mm
At right angles to an access route at least 1500 mm wide	800 mm
At right angles to an access route at least 1200 mm wide	825 mm
External doors and internal lobby doors at the entrance of buildings used by the general public ^(b)	1,000 mm
Entrance door to a changing places toilet	1,000 mm
NOTES: (a) The effective clear width should be measured in accordance with Diagram 10. (b) Buildings used by the general public include day centres, hotels, institutional buildings, places of assembly, shops, shopping centres and office buildings with a nett floor area^(c) per floor greater than 200 m². (Refer to Section 0.6(d) for definitions) (c) When calculating the nett floor area of any storey, the area provided for vertical circulation, common sanitary facilities and maintenance areas in the storey should not be included.	