



For thermal blockwork 1:1:6
Cement/lime/sand mix must be used above dpc level – 1:4 cement/sand with plasticizer is to be used for below dpc level. Moisten lime to form a lime putty before adding the cement and sand.

A dash of mortar mix may be added. If necessary, dampen the blockwork with a brush to overcome surface absorption before laying the mortar. Alternatively other designation III readmix mortar can be used as listed in BS 5628-3:2005 Code of practice for the use of masonry – Materials and components, design and workmanship.