




Door Type 1 (8 no)
D1, D2, D3, D4,
D5, D7, D8, D9.
Door is FD 30 Primed
clear Pyro glass Fire door



Door Type 2 (4 no)
D6, D10, D11, D 12.
Door is FD 30 Primed
Fire door



Screen Typ 1
S1, S3, S5, S7,
S10, S12, S13.
Screen 30 min rated,
with opening sash.



Screen Typ 2
S2, S4, S6, S8, S9,
S10, S12, S13.
Screen 30 min rated,

DOOR SCHEDULE