SECTION 20

Driver's Signal Window Refurb

a) Remove bottom rail of frame and front & rear sliding glass bottom rails.

b) Fit new rails supplied by BAC.

c) Seal bottom corners of Driver's Signal Window frame.